





**HQ PUMPS S.r.l.**

**INSTRUCTIONS FOR INSTALLATION AND MAINTENANCE**

**HQ TANK 220 - HQ TANK 580**









*Traduzione delle Istruzioni Originali*  
*Translation of Original Instructions*

## CONTENTS

<b>1. WARNINGS</b>	<b>3</b>
<b>2. RESPONSIBILITY</b>	<b>3</b>
<b>3. MANAGEMENT</b>	<b>3</b>
3.1 <i>Storage</i>	<b>3</b>
3.2 <i>Transport</i>	<b>3</b>
<b>4. EXAMPLE OF INSTALLATION</b>	<b>4</b>
4.1 <i>Dimensions HQ TANK 220</i>	<b>5</b>
4.2 <i>Dimensions HQ TANK 580</i>	<b>5</b>
<b>5. TANK INSTALLATION</b>	<b>6</b>
5.1 <i>Placing the tank inside the building</i>	<b>6</b>
5.2 <i>Placing the tank outside the building</i>	<b>6</b>
5.3 <i>Connecting the delivery pipe to the sewer network</i>	<b>6</b>
5.4 <i>Connecting the ventilation pipe</i>	<b>7</b>
5.5 <i>Non-return valve</i>	<b>7</b>
5.6 <i>Interception gate valve</i>	<b>7</b>
<b>6. PUMP INSTALLATION</b>	<b>7</b>
6.1 <i>Positioning of the pump inside the tank - without foot coupling -</i>	<b>8</b>
6.2 <i>Positioning of the pump inside the tank - with foot coupling -</i>	<b>9</b>
<b>7. ELECTRICAL CONNECTIONS</b>	<b>9</b>
<b>8. FIRST START-UP</b>	<b>10</b>
8.1 <i>Operating flow rate</i>	<b>10</b>
8.2 <i>Operation</i>	<b>10</b>
<b>9. MAINTENANCE</b>	<b>10</b>
<b>10. TROUBLESHOOTING</b>	<b>11</b>
<b>11 DISPOSAL</b>	<b>11</b>

## 1. WARNINGS

- 1.1  **Before installation, carefully read this documentation and that supplied with the pump manual and the control panel.**  
It is indispensable to have the electric and hydraulic connections made by skilled personnel, in possession of the technical qualifications indicated by the safety standards concerning the design, installation and maintenance of technical plants, in force in the country where the product is to be installed. Failure to comply with the safety regulations not only causes risk to personal safety and damage to the equipment, but invalidates every right to assistance under guarantee.
- 1.2  The term skilled personnel means persons whose training, experience and instruction, as well as their knowledge of the respective standards and requirements for accident prevention and working conditions, have been approved by the person in charge of plant safety, authorizing them to perform all the necessary activities, during which they are able to recognize and avoid all dangers. (Definition for technical personnel IEC 364). The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- 1.3  Check that the system has suffered no damage during transport or storage. In particular, ensure that the external casing is perfectly entire and in excellent condition; check the efficiency of all the tank components; replace any parts that are not perfectly efficient.
- 1.4  Do not use inflammable or highly corrosive liquids or anything other than indicated by standard EN 12050-2.
- 1.5  If the installation is indoors, adequate drainage must be ensured in the event of leakage from the tank.
- 1.6  For correct installation, follow the instructions in chapters 3-4-5 below. If you want to install the HQTANK lifting tanks outside the home, **attention must be paid because the maximum admissible load on the cover is 100 kg (see also the symbols on the cover).**

## 2. RESPONSIBILITY

The Manufacturer does not vouch for correct operation of the machine or answer for any damage that it may cause if it has been tampered with, modified and/or run outside the recommended work range or in contrast with other indications given in this manual.

## 3. MANAGEMENT


### 3.1 Storage

All the products must be stored indoors, in a dry, vibration-free and dust-free environment, possibly with constant air humidity.

### 3.2 Transport

Avoid subjecting the products to needless jolts or collisions. To lift and transport the tank, use lifting equipment and the pallet supplied standard (if applicable).

#### 4. EXAMPLE OF INSTALLATION



Le HQTANK 220 and HA TANK 580 are preassembled systems, ready for installation, requiring no adjustment, ideal for collecting and disposing of sewage and domestic waste water from basement rooms, situated below the level of the sewer network. In compliance with the accident-prevention regulations in force, the HQTANK 220 - 580 cannot be used for conveying inflammable or explosive liquids, such as petrol, diesel fuel, combustible oils, solvents, etc.

- 1 - Interception ball or gate valve
- 2 - Delivery
- 3 - Siphon

- 4 - Ventilation
- 5 - Collecting pipe
- 6 - No Return Valve




Fig. 1



Fig. 2





Fig. 3


### 4.1 Dimensions HQ TANK 220

The dimensions below are given in millimetres.



### 4.1 Dimensions HQ TANK 580

The dimensions below are given in millimetres.



## 5. TANK INSTALLATION

The lifting stations of the HQTANK 110 series have various inlet and outlet possibilities for the pipes. Depending on the type of installation and on the local standards in force it may be necessary to provide a siphon, a non-return valve on the pipe connecting to the public/private sewer network or to other ducts. Always refer to the local and/or national regulations, laws and standards in force. Anyway it is recommended to install check valves and interception valves upstream and downstream from the station. An example of installation is shown in chapter 4.



All the ducts must be installed in such a way that they are not stressed. The ducts must not exert stress on the station. Check that the electropump is securely fixed to the pipes and that all the hydraulic connections are tightened and watertight.

Where necessary provide suitable means for avoiding the transmission of vibrations and for protecting the pipes against the formation of ice.

### 5.1 *Placing the tank inside the building*

The tank may be laid on the floor, under the ground or housed in a masonry pit. Fig.2, Fig.3. **In any case the surface on which it is laid must be perfectly horizontal and it must be ensured that the whole bottom of the tank is in contact with the surface.**



Leave a free space of at least 60 cm around and above the station for installation and maintenance.

### 5.2 *Placing the tank outside the building*

If the tank would not be buried, to prevent damage to itself and to the seals, you should not expose it to heat sources such as direct sunlight can be at certain times of the year.



Do not position the lifting station directly on the ground. The site chosen must not have ground water and must not be subject to flooding. Suitable anchor the station so as to avoid rotation and floating. For this you can use the slots on the base of the tank.

There must be a horizontal base suitable to bear the weight of the station during its operation. Depending on the characteristics of the terrain it may be necessary to create walls with bricks, prefabricated components or concrete. Fill the space between the ditch and the station with sand and compact it suitably. Protect the station suitably against frost.



Do not drive vehicles over the cover (see fig. 3).

You can close the ditch with a cover (manhole) or other means for facilitating subsequent maintenance. Put up suitable signals indicating the presence of the station so as to avoid possible damage caused unintentionally. Ensure that there is sufficient space for installation and maintenance around and above the lifting station.



Position any capacitor holder and/or electric control panel in a place sheltered from the elements.

After having completed the hydraulic and electric connection, it is recommended to place clean sand around the container to reduce any movements caused by the system and/or by the surrounding terrain.

### 5.3 *Connecting the delivery pipe to the sewer network*

HQTANK 220-580 tanks have a 2" GAS outlet connection.

To guarantee a perfect seal it is recommended to use Teflon or suitable glues depending on whether the material being glued is plastic (PP or PVC) or metal.

#### 5.4 Connecting the ventilation pipe

Remember to provide a ventilation pipe to avoid the formation of inflammable, explosive or toxic mixtures. On the station identify the seat for the ventilation duct DN50. Check that the coupling is watertight. The various national regulations may require different ratios between the diameter of the outlet pipe and that of the ventilation pipe. Ensure that the pipe outlet is in the open (for example, above the ridge of the roof if the station is installed inside a building) and that the exhaust gases cannot get into other places such as buildings, rooms and similar. Avoid horizontal stretches in the ventilation duct.

#### 5.5 Non-return valve

Install a non-return valve in the pipe connecting to the public/private sewer network. This will avoid the reflux of liquid. Place the valve at a distance of at least 1 metre from the lifting station to allow the flow of liquid, moved by the pump, to open the shutter of the valve (unless indicated otherwise by the manufacturer). Always refer to the local and/or national regulations, laws and standards in force. The non-return valves are available as accessory kits.

#### 5.6 Interception gate valve

Install an interception valve in both the inlet pipe and the delivery pipe (connection to the public/private sewer network). In this way maintenance work can be carried out without having to drain the whole system. Gate valves or ball valves may be used.

The interception valves are available as accessory kits.

**NOTA** See example of installation in chapter 4.

### 6. PUMP INSTALLATION



Ensure that the difference in level between the pump and the sewage network is compatible with the pump performance and the correct rotation of the impeller (only for three-phases pumps).

Make sure that the difference in height between the pump and the sewer system is compatible with the performance of the pump

The HQTANK 200-580 model are fitted with a 2" threaded delivery pipe and with connections for positioning the inlet pipe (DN110) and the ventilation pipe (DN 50) - see fig.6.

HQ Tank supply

Detail of the delivery pipe without coupling device




Fig. 6




Fig. 6-a

### 6.1 Positioning of the pump inside the tank - without foot coupling -

- 1) Unscrew the ring nut (C) and detach the delivery pipe (C1 + D + E) from the 2" threaded outlet connection (A) - see fig. 6-a
- 2) Positioning the delivery pipe on the VS.40V.04.2.110L pump, screwing the 2" threaded hex (E) on the pump delivery port. - see fig. 7
- 3) Unscrew the nuts (B) that keep the 2" threaded outlet (A) locked to the tank, so as to have a vertical clearance in order to facilitate the coupling of the pump to the 2" outlet of the tank - see fig. 8 and 9




Fig. 7

- 4) Positioning the pump inside the tank by aligning the delivery pipe (D + C1) with the screw ring nut (C). Screw the ring nut (C) on the thread (C1) of the pipe - see figs. 8-9.
- 5) Tighten all the threaded nuts (B) in order to block the 2" threaded outlet pipe (A) to the tank - see fig. 9.




Fig.8



Fig.9




## 6.2 Positioning of the pump inside the tank - with foot coupling -

1) Positioning the sliding bracket (A) on the pump delivery flange with the nuts, bolts and gaskets supplied with the pump.



2) Lift the pump using the lifting ring or handle, positioned on the top of the pump and lower it inside the tank by positioning the slide so as to embrace the guide tubes (B).



3) Slide down the pump until it stops on the coupling device positioned on the bottom of the tank. The weight of the pump itself will create the coupling which pump and foot coupling necessary for the expulsion of the

Note : There may be a slight flow of fluid between the foot and the pump which, over time, will decrease until it completely disappears.

SUITABLE FOR FOLLOWING PUMPS:

HQ TANK 220 HQ TANK 580	VS.40V	ALL MODELS M - MA - T - TA FROM 0,4 KW UP TO 2,2 KW
	VS.40H	
	VSL.50	
	VS.50	
	GS.50	

## 7. ELECTRICAL CONNECTIONS

Before connecting the system to the mains, ensure that the mains voltage is the same as the value indicated on the pump data plate. It is recommended to apply the pump data plate (supplied in the package in addition to the one already applied on the pump by the manufacturer) on the tank, in a clearly visible position, or on the control box.

The connection must be made as follows:

**Pump:**

Pass the pump cable through the cable gland supplied in the kit.  
Then tighten the ring nut of the cable gland inside the tank.

**Possible float:**

Pass the float cable through the cable glandsupplied.  
Then tighten the ring nut of the cable gland inside the tank.

## 8. FIRST START-UP



Before starting up the electropump check that in the tank system there is no residue or other material that could harm the correct operation of the system.

In this phase you can leave the interception valve in the inlet pipe closed and fill the lifting station with clean water. Open the interception valve in the delivery pipe and check that the pipes are tightened and perfectly sealed and that the electropump is working correctly. Check also that the electropump is primed. Open the interception valve in the inlet pipe and check that the station is working correctly.



The flow of liquid coming from the various utilities must not prevent the correct operation of the floats present in the container.

In the case of a three-phase electropump, **check** that the impeller is turning in the correct direction. **Check** also the electropump manual. **Check** that the levels of float intervention are correct, and if necessary adjust them to suit the actual needs of the system. When there are two electropumps, the floats must be adjusted so that the second pump starts after the first and only if the first is not able to send to the sewer duct as much liquid as arrives from the various utilities. **Check** that the electropump cannot become unprimed during operation. **Check** that the number of starts per hour is compatible with the characteristics of the system components. **Check** that the system is working correctly and put it into service. Close the cover or covers of the station, screwing them into place.

### 8.1 Operating flow rate

It must be guaranteed that the speed of the liquid in the delivery pipe is at least 0.7 m/s and lower than 2.3 m/s.

### 8.2 Operation

When the liquid in the tank reaches the level corresponding to the closure of the float contact that commands the electropump, the pump starts and gradually empties the tank. The electropump stops when the liquid reaches the minimum level corresponding to the opening of the float contact. When there are two electropumps (HQ TANK 580), the floats must be adjusted so that the second pump starts after the first and only if the first is not able to send to the sewer duct as much liquid as arrives from the various utilities. There may be a float placed higher than the others in the pumping station, its function is to indicate the presence of an abnormally high level of the liquid in the tank.

## 9. MAINTENANCE

After starting up the plant, it is advisable to inspect and clean it, especially the no return valve, about every three months. This interval may be increased after the first inspections have given a favourable outcome. Clean the pump accurately, removing any foreign bodies stuck in the intake grille and check that the float moves freely. If necessary, remove the pump from the tank.

It is recommended to clean the system at least once a year with running water, operating the pump repeatedly.

## 10. TROUBLESHOOTING

FAULTS	CHECK - POSSIBLE CAUSES -	REMEDY
<p>1. Water is overflowing from the tank and the pump is not working.  (In this situation the alarm, if installed, must intervene. Otherwise check the alarm system installation instructions).</p>	<p>A. Delivery pipe blocked. B. The pump is not correctly connected to the delivery pipe. C. No return valve blocked. D. Interception valve closed. E. Pump characteristics are insufficient. F. The pump intake grille is blocked. G. The impeller is worn or blocked by foreign bodies.</p>	<p>A. Remove the obstructions. B. Check that the pump slide is at its full limit (only for tanks &gt; = of 280 l ).  C. Clean the valve. D. Open the valve. F. Remove the obstructions. G. Remove the obstructions.</p>
<p>2. The alarm, if installed, intervenes, but the system operates</p>	<p>A. Check the exact position of the alarm float</p>	<p>A. Repeat the checking and installation operations.</p>

## 11. DISPOSAL

This product or any part of it must be disposed of correctly:

1. Use public or private local systems for waste collection.
2. If it is not possible, contact HQ Pumps or the nearest authorised service workshop.



## **HQ PUMPS S.r.l.**

**Sede Operativa / Operative Site**

Viale Industria 47-L  
27010 San Genesio ed Uniti (PV) - ITALY  
Tel. 0382.586457

**Sede Legale / Head Office**

Strada Statale dei Cairoli, 8  
27020 Carbonara al Ticino (PV) - ITALY

**[www.hqpumps.it](http://www.hqpumps.it)**